

Torque Converter Installation Guide Lines

The T72 Series of transmissions requires a hydraulic torque converter to match driving torque to load and grade. All T72 Series transmissions are designed to use a standard eleven-inch (280mm) torque converter. Proper installation is essential for reliable operation.

The installation drawing below should be used as a guideline for torque converter installation. Dimension "A" must be maintained to insure a recommended nominal tang engagement. For illustration purposes a standard eleven-inch (280mm) torque converter is used.

